

# HOW TO WATCH TV

1 / Switch on the TV:

Press the "TV" button on the TV remote control (a red dot is shown).  
See **yellow arrow** on the photo on the right.

2 / If you do not see anything on the screen but only a message "! No Signal ", press the " TV "button again (**yellow arrow** on the photo on the right). You will now see the last selected channel that was watched before the TV was last shut down.

3 / with the gray buttons around "OK" you can zap between the channels or enter the channel number with the number keys.

4 / To switch off the TV:

Press the red round button



**AFTER USE ALWAYS PUT THE REMOTE BACK ON THE WHITE TABLE UNDERNEATH THE TV**